() rehab Padding for side support - low armrest

Art. no.: 69686, 69687

Art.no.: 95823-1 Rev. A Latest revision: 2013-02-15

User manual / Assembly instructions Page 1 (1)

Parts included:



Assembling

Start with putting the front part of the side support into the deep pocket of the padding and thereafter put the smaller pocket of the padding over the rear end of the side support. This can be a bit difficult because of the fit being tight. When it's done it should look like this:



Use and Care instructions

The padding can be cleaned by wiping with soap and water. For further information, see the Maintenance Instructions, art. no. 95730-1.